

TITLE: QUICK GUIDE FOR ADJUSTING TIME (DST) FOR YBP OR YMP SIGNAL PROGRAMMERS

INSTRUCTION SHEET: 3182

REVISION: 01

EFFECTIVE:12-07-2018

YMP/YBP SERIES MASTER WITH 2-DIGIT YEAR

TO SET THE TIME:

1. Press **RUN**.
2. Press **SET** - notice the small black (non-blinking) cursor beneath the minute digit.
3. Push and hold **FWD** and the minutes will start advancing...slowly at first, then faster after a couple of seconds. Release the button when you get close to the time you wish to enter. Then advance the minutes slowly by pressing **FWD** until the correct time is indicated.
4. At this point, if you only want to adjust the time, you can push **RUN** to get out of **SET** mode.
Note: You will not be able to back up when setting the time, so if you go past the time you need to enter, you will need to advance through nearly 24 hours to get back to the desired time. Also verify that the AM/PM on the right side is correct.

YMP/YBP SERIES MASTER WITH 4-DIGIT YEAR

TO SET THE TIME:

1. Press **RUN**.
2. Press **SET**- a non-flashing cursor will appear below the seconds. This cursor indicates the element that may be changed using the **FWD** key. The seconds should be changed last unless only changing the seconds portion of the time.
3. Press **ENT** to move to the minutes field. Use the **FWD** key to adjust the minutes. While setting the time it continues to run. Wait until the minutes changes before making final minute adjustments. This will allow the maximum time to enter the minute portion of the time.
4. Press **ENT** to move to the hours field. Use the **FWD** key to adjust the hour. The YMP/YBP PLUS MASTER operates on a 24 hour cycle. To change between AM and PM you must press the **FWD** key an additional 12 hours.
5. Press **RUN** to return to normal operation

Visit www.american-time.com/resources/discontinued to read the full manual.